

AMPHENOL INTERCONNECT	REV:	DOC.NO:
INDIA PVT. LTD.	REL DATE:	CL. NO.: 7.5.1
WORK INSTRUCTION	PAGE 1 OF 4	DEPT./SEC: Assembly


Objective-This document defines the operation of cable assembly of 164 series plug connector with necessary inspection instructions.

Assembly Procedure-

- 1) Remove the connector carefully from the packing bag.
- 2) Dis assemble the connector for assembly of cable with insert.








Take out the insert from the dis assembled connector separately for soldering.

Prepared by	Checked by	Approved By
NNK	AMP	CSM

AMPHENOL INTERCONNECT	REV:	DOC.NO:
INDIA PVT. LTD.	REL DATE:	CL. NO.: 7.5.1
WORK INSTRUCTION	PAGE 2 OF 4	DEPT./SEC: Assembly

4)



Solder the cable with the contacts in the insert properly

Check for proper soldering.

Check that no excess solder metal is spread around outer periphery of Contact

Clean insert subassembly with IPA (Isopropyle Alcohol)

Inspection-

Check for Insulation Resistance as per standard Check for Break down voltage as per standard

5)




Assemble all the parts of connector through cable as per sequence of assembly.



Prepared by	Checked by	Approved By
NNK	AMP	CSM

AMPHENOL INTERCONNECT	REV:	DOC.NO:
INDIA PVT. LTD.	REL DATE:	CL. NO.: 7.5.1
WORK INSTRUCTION	PAGE 3 OF 4	DEPT./SEC: Assembly



Broaching Keys of shell

Keys of Insert






Matching Keys of Shell & Insert


Match the Key ways of the shell & Insert Press the insert in the shell.

Fit the insert properly in its position in the shell










Assemble & press remaining parts in the shell Check that all parts are located properly inside the shell


Prepared by	Checked by	Approved By
NNK	AMP	CSM

AMPHENOL INTERCONNECT	REV:	DOC.NO:
INDIA PVT. LTD.	REL DATE:	CL. NO.: 7.5.1
WORK INSTRUCTION	PAGE 4 OF 4	DEPT./SEC: Assembly



Lock adapter nut & other accessories to the shell.





Use proper size spanners for tightening of adapter nut & Gland Nut Use appropriate torque while tightening.

Prepared by	Checked by	Approved By
NNK	AMP	CSM